BIO-MEDICAL WASTE MANAGEMENT

Introduction

All human activities produce waste. We all know that such waste is a problem, but we rarely think about the scale of the problem. Industrial and agricultural waste attract most public attention, but still we do not like dangerous to human beings and environment. Similarly, hospitals and other medical establishments generate a variety of wastes during the diagnosis, treatment or immunization of human beings or animals or in research activities pertaining thereto or in the production or testing of biological.

Such quantities of the world, especially the developing nations, are not properly managed and thus pose a serious and significant environmental pollution due to anthropogenic activities. Risk to the general public from increasing exposure to infectious agents, toxic and hazardous chemicals and radioactive substances is of great concern. Every year 12,000 small and private hospitals and nursing homes in the country. This is apart from the waste generated by pharmaceutical labs, medical labs, diagnostic laboratories

amounts of medical waste.

India generates around three million tonnes of medical waste every year and the amount is expected to grow at 8% annually. Hospitals in Delhi alone generate around 350 tonnes of waste. Other major cities in the country such as Mumbai, Maharashtra, Surendra and Tamil Nadu also generate large amounts of medical waste.

Surveys carried out by various agencies show that the health care establishments in India are not giving due importance to the management of the waste generated by them. Most of the hospitals and nursing homes in India are not aware of the various rules and laws prescribing the process of waste segregation, collection, transportation and treatment. Many of the larger hospitals have either installed the treatment facilities or are in the process of doing so.

Bio-medical waste

Bio-medical waste means "any solid and/or liquid waste including its container and any intermediate product, which is generated during the diagnosis, treatment or immunization of human beings or animals".

Biomedical waste poses hazard due to two principal reasons - the first is infectivity and other toxicity.

Bio-Medical waste consists of

- Human anatomical waste like tissues, organs and body parts
- Animal waste generated during research from veterinary hospitals
- Microbiology and biotechnology wastes
- Waste shares like foundations needles, syringes, scalpels and broken glass
- Discarded medicines and cytotoxic drugs
- Soiled waste such as dressing, bandages, plaster casts, material contaminated with blood, tubes and catheters
- Liquid waste generated in the infected areas
- Incineration ash and other chemical wastes

Legal aspect

The Central Government, to perform its functions effectively as contemplated under sections 6, and 25 of the Environment (Protection) Act, 1986, has made various Rules, Notifications and Guidelines from time to time in relation to Environment Protection Act, 1986.

A brief summary of the provisions in Bio-medical Management & Handling Rules, 1998 is given below.

- Section 3 establishes the authority of the Government to undertake various steps for protection and improvement of the environment.
- Section 5 provides for the manner of directions in writing.
- Section 6 empowers the government to make rules.
- Section 8 permits the publication of Notification dealing with hazardous wastes regarding various safety measures.
- Section 23 bestows authority to enter the premises and inspect.
- Section 25 allows the government to appoint such persons as government officers. This involves improvement up to five years or penalty of rupees one lakh or both. In case the default continues, it could then attract a penalty of rupees five thousand for every day during which such default continues after the first day.
- Section 26 provides for punishment by a court of cognizance for offences committed.

Even after the June, 2000 deadline most of the large hospitals have not complied with these Rules, as there is no specified penalty for failure in the implementation of these Rules. The only way to do that is by way of the orders of the Supreme Court or the High Courts. Some of the hospitals have either installed the treatment facilities or are in the process of doing so to enforce the Rules.

Applicability of BMW Rules, 1998

The BMW Rules are applicable to every occupier of an institution generating biomedical waste which includes a hospital, nursing home, clinic, dispensary, veterinary institution, animal house, pathological laboratory, blood bank, etc.

Common Biomedical wastes treatment facility (CBWTFs)

The Rules envisage setting up of CBWTFs as per the rule 19, amended in June 2000, which cast the responsibility on the occupier to ensure treatment and disposal of biomedical waste in accordance with these rules either by setting up of incinerator/s, the owner of CBWTFs are service providers who are providing services to health care units for treatment and disposal of bio-medical waste.

Guidelines of CBWTFs

The Tamilnadu Pollution Control Board enforces the Biomedical Waste (Management and Handling) Rules, 1998 as per the Rule 19 of the Rules, the Board has issued the guidelines for the setting up of CBWTFs for the benefit of the private hospitals. The Board of Bio-medical waste requires for categorization as a first step. The BWW Rules classify the BMW into ten categories.

CATEGORIES OF BIOMEDICAL WASTE SCHEDULE - I

WASTE CATEGORY	TYPE OF WASTE	TREATMENT AND DISPOSAL METHODS
Category No. 1	Human Anatomical Waste like human tissues, organs, body parts	Incineration@ / deep burial*
Category No. 2	Animal Waste Animal tissues, organs, body parts, carcasses, bleeding parts, fluid, blood and waste/discarded animal used in research, waste generated by veterinary hospitals, colleges, animal houses, etc.	Incineration@ / deep burial*
Category No. 3	Microbiology & Biotechnology waste (Wastes from laboratory cultures, stocks or specimens of live micro-organisms or attenuated strains of micro-organisms used in research laboratories, waste from production of biological, toxins, dish culture and devices used for transfer of cultures)	Local autoclaving/ Microwave/ incineration@ / autoclaving / microwaving and incineration@ / chemical disinfection@ / autoclaving / shredding*#
Category No. 4	Waste Sharps Needles, syringes, scalpels, blades, glass, etc. that may cause injuries and cuts. This includes both used and discarded sharps)	Disinfecting (chemical treatment@@) / autoclaving / microwaving and shredding*#
Category No. 5	Discarded Medicine and Cytotoxic drugs (Wastes comprising of outdated, contaminated and discarded medicines)	Incineration@ / destruction and drugs disposal in secured landfills*
Category No. 6	Soiled Waste (Items contaminated with blood, fluids including cotton, dressings, soiled plaster casts, linen, beddings, other material contaminated with blood)	Incineration@ / autoclaving / microwaving*
Category No. 7	Solid Waste (Waste generated from disposable items other than the waste sharps such as tubing, catheters, intravenous sets, etc.)	Disinfection by chemical treatment@@ / autoclaving / microwaving and mutilation / shredding*#
Category No. 8	Liquid Waste (Waste generated from the laboratory and washing, cleaning and housekeeping activities)	Disinfecting by chemical treatment@@ and discharge into drains
Category No. 9	Incineration Ash (Ash from incineration of any biomedical waste)	Disposal in municipal landfill*
Category No. 10	Chemical Waste (Chemicals used in production of biologicals, chemicals used in disinfection, as reagents for diagnostic purposes, etc.)	Chemical treatment@@ and discharge into drains for liquids and secured landfill*

@@ Chemical treatment using at least 1% hypochlorite solution or any other equivalent chemical reagent. It must be ensured that chemical treatment ensures disinfection.

** Mutilation / Shredding must be such to prevent unauthorized reuse.

\# Shredding may be resorted to as a treatment before incineration. Chemical plastics shall not be incinerated.

* Deep burial shall be an option available only in towns with population less than five lakh and in rural areas.

COLOUR CODING AND TYPE OF CONTAINER/ BAGS/BIN USE



Colour Coding	Type of Container	Waste Category	Treatment options as per Schedule I
Yellow	Plastic bag	Cat. 1,2,3,6 Cat.1 and 4 (a)	Incineration/ deep burial
Red	Disinfected container/ plastic bag	Cat.3, Cat.6, and Cat. 7 (part)	Autoclaving/Micro-waving/ Chemical Treatment and destruction/ shredding
Blue/ White translucent	Plastic bag/ puncture proof container	Cat. 4 and Cat.7 (part)	Autoclaving/Micro-waving/ Chemical Treatment and destruction/ shredding
Black	Plastic bag	Cat. 5, Cat.8, and Cat.10 (solid)	Disposal in secured landfill

Note:

1. Colour coding of waste categories with multiple treatment options as defined in Schedule I, it shall be selected based on treatment option chosen, which shall be specified.
2. Waste collection bags for waste bags needing incineration shall not be made of chlorinated plastics.
3. Categories 6 and 10 (liquid) do not require any containers.
4. Category 7 if disinfected locally need not be put in containers/bags.

Composition of BMW

The typical hospital solid waste composition is as follows (based on 1418 report)

Segregation

Segregation refers to the basic separation of different streams of waste generated in a hospital. Segregation is the most important step in the waste management. Effective segregation alone can ensure effective bio-medical waste management. Segregation at source is essential to avoid mixing of hazardous waste with non-hazardous waste.

How does segregation help?

- Minimizes the overall amount of waste needs special handling and treatment.
- Effective segregation process prevents the mixture of material waste like glass, plastic, paper, food waste, etc.
- Prevents the contamination of non-hazardous waste like food waste, paper, sachets and other plastics.
- Provides an opportunity for re-using components of medical waste like metal implants, glass bottles, plastic bottles, etc.
- Recycled plastic material can be used for non-food grade applications.
- If the general waste, the biodegradable waste can be composted within the hospital premises and can be used for gardening purposes.
- Segregation helps in cost effective treatment practice, which can also results in a more environmentally friendly practice.
- Reduces the cost of treatment and disposal (50 per cent of a hospital's waste is non-hazardous, but if mixed with hazardous waste, the entire quantity is considered and treated with other infectious waste).

Proper labelling of bins

The bins and bags should carry the biohazard symbol indicating the nature of waste to the patients and public.

Label shall be non-washable and prominently visible.

Collection



The collection of biomedical waste involves use of different types of container from various sources of biomedical waste. The collection of biomedical waste is done in such a way that it does not cause any damage to the bags or bins. It is also important to disinfect the containers. Protective gloves should be worn by the personnel while collecting the waste.

Storage

Once collection occurs then biomedical waste is stored in a proper place. Segregated wastes of different categories need to be collected in identification containers. The duration of storage should not exceed for 6 hr in to by hospitals and 24 hr in case of CBWTFs. The storage area should be away from the public view and should be easy to clean and disinfect. The storage area should be designed in such a way that no rainwater is there the waste back to its source.

Transportation

The waste should be transported for treatment within 4 hrs/less or it in covered virtualborne. Manual loading should be done in such a way that the bags or bins are not damaged. Transportation of waste within the premises should be through dedicated transporters in the bags and containers. Finally, it should be accompanied with a signed document to honor District Monitoring Desk, GPS system and Accident Reporting.

Transportation of waste outside the premises is a different scenario to, and direct contact with, the waste by the transportation operatives. On transportation and the bags, the biodegradable waste can be composted within the premises. The effects of traffic problems should be considered in the routes, and the driver must be trained in the procedures he must follow in case of accidents. Transportation of waste within the premises should be through dedicated transporters.

Personnel safety devices

The use of protective clothing should be made mandatory for all the personnel handling waste.

Gloves, aprons, gumboots and masks should be used for waste handling by the sanitary workmen. This should be forged before in certain after handling the waste, the gloves should be washed twice. The gloves should be washed after every use and discarded when they are torn or punctured. Gloves

Gloves, aprons, gumboots and other separators required to work to prevent contamination of clothing and protect skin. It could be made of cloth or impermeable material such as plastic. People working in incinerator chambers should have protective clothing and heat resistant gloves.

Masks: Various kinds of masks, respirators and face shields are worn alone or in combination, to provide a protective barrier. It is mandatory for personnel working in the incinerator chamber to wear a mask covering both nose and mouth. Masks should be worn at all times.

Boots, Low-cut boots, boots or shoes should provide proper protection to the skin when sedentary or huge quantities of infected waste have to be handled. The boots should be rubber-soled and anti-skid sole. They should cover the leg and to the ankle.

Gloves

Masks

Boots

Aprons, gowns, suits or other apparels

Cleaning devices

The cleaning of bins shall be a minimum of 1 in long, such that the waste used ink stains to sweep. The disinfectant solution should be used for cleaning the bins. The brush of the broom shall be soft or hard depending on the floor to be swept.

Equipment

The equipment that should be used to collect the dust from the sweeping operations. They may be either of pedal or wooden shafts. They should be free of bits and should have smooth contours, to prevent dust from sticking to the surface. They should be used with disinfectants and should not be worn out.

Trolleys

Trolleys are used for the transportation of waste from the point of generation to the storage area. The trolley may be two-wheeled depending on the load and size. The mechanical lifters must if they is convenient for separating out the refuse.

Containers: Vacuum cleaners or industrial vacuum cleaners can be used depending on the size of the refuse.

Storage devices

Dustbins

It is non-important to assess the quantity of waste generated at each point. Dustbins should be of such capacity that they do not overflow between the two periods of cleaning. Dustbins should be of such a size that they can be easily handled by persons with disinfectants. Dustbins can be lined with plastic bags, which are chlorine free, and colour coded as per the law.

Handling devices

Trolleys

The use of trolleys will facilitate the removal of infectious waste at the source of generation to the storage area or treatment plant.

Wheelbarrows

Wheelbarrows are used to transfer the waste from the point source to the storage area or treatment plant. The wheelbarrow should be of such a size that it can be easily handled and provided with two wheels and a handle. Care should be taken not to directly dump waste into it. Cloth, gunny sacks or plastic bags should be used to collect the waste and then put in the wheelbarrow. Wheelbarrows should be used for transferring debris only.

Trolleys

Trolleys are vertical conduits provided to carry waste from transportation of refuse vertically in case of multi-storied buildings. Trolleys are normally provided in hospitals, hotels, industrial houses, etc. Trolleys should have a self-closing lid. These shutter should be fumigated everyday with formaldehyde vapours. The floor openings should be provided with self-closing doors on each floor. The floor openings should be provided with a limited door in or plastic bags before packing into the cycle.

Chemically, deviation with mechanical vehicles or electrical vehicles can be provided to bring the refuse from the storage point to the treatment plant. Such vehicles should be designed in such a way that they minimize the scarcity of the waste within the premises and hence reducing the risk of secondary contamination.

Treatment

Technologies options for Treatment

There are many different technology options available for the treatment of the Medical Waste or still under research can be grouped as

1. Chemical processes
2. Thermal processes
3. Mechanical processes
4. Irradiation processes
5. Biological processes

These processes can theoretical that all sterilization, Sodium hypochlorite, Alcohol,chlorine dioxide, peracetic acid, Glutaraldehyde, Formaldehyde, Ozone, Hydrogen peroxide and wastes are example of such chemical. Here chemical processes are used to destroy the pathogens in the waste.

2. Thermal processes

These processes are also heat is disinfect. Depending on the temperature they operates it to lower program into two categories, which are Low heat and High heat thermal processes.

- Low heat thermal processes are operated at temperatures below 100°C and are used for shredded and decontaminate the waste.
- Autoclave & Microwave are two heat systems.

Autoclaving is a low heat thermal process and it uses steam for treatment of waste. Microwaving is also a low heat thermal process method they use for removal of all pockets and gravity flow autoclave and vacuum autoclave.

Microwaving is a process which disinfect the waste by moist heat and steam generated by microwave energy.

High heat systems (operates between 540-6,100°C) employ combustion and high temperature plasma to decontaminate and destroy the waste.

Incineration is a fire-technology pro high heat systems. Incineration - Is a burn technology



3. Mechanical processes

These processes are used to change the physical form or characteristics of the waste rather to facilities waste handling, to make it safer, to reduce volume, to increase later operation with other treatment steps. The two primary mechanical processes are

Compaction - used to reduce the volume of the waste.

Shredding - used to destroy plastic and paper waste to prevent their reuse. Only the disinfected waste can be used in shredding.

4. Irradiation processes

Using ionizing radiation (electron or ionizing radiation in an enclosed chamber. These systems require part shredding to reduce the waste volume before.

5. Biological processes

Using biological processes for treating medical waste. It is claimed that biological reactions will not only decontaminate the waste but also cause the destruction of all the organic constituents so that only plastics, glass, and other inert stuff will be left behind.

Methods to avoid in the processing of waste

Incineration

- Incinerators should be suitably designed to achieve the emission limits.
- Wastes to be incinerated shall not be chemically treated with any chlorinated disinfectants.
- Toxic metals in the incineration ash shall be limited within the regulatory quantities.
- Only low sulphur fuel like Diesel shall be used as fuel in the incinerator.

Autoclaving

The autoclave should be dedicated for the purpose of disinfecting and treating biomedical waste.

1. When operating a plastic flow autoclave, medical waste shall be subjected to:
   - A temperature of not less than 121 oC and pressure of about 15 pounds per square inch (psi) for an autoclave residence time of not less than 60 minutes, or
   - A temperature of not less than 135 oC and a pressure of 31 psi for an autoclave residence time of not less than 45 minutes, or
   - A temperature of not less than 149 oC and a pressure of 52 psi for an autoclave residence time of not less than 30 minutes.
2. When operating a vacuum autoclave, medical waste shall be subjected to a minimum of one pre-vacuum pulse to temperature of 134 oC for a residence time of not less than 45 minutes.
   - A temperature of not less than 121 oC and a pressure of 15 psi for an autoclave residence time of not less than 45 minutes, or
   - A temperature of not less than 135 oC and a pressure of 31 psi for an autoclave residence time of not less than 30 minutes, or
   - A temperature of not less than 149 oC and a pressure of 52 psi for an autoclave residence time of not less than 20 minutes.
3. Each autoclave shall be provided with suitable, calibrated pressure gauge and thermometer to monitor the time, temperature and pressure indicator shall be provided. If for any reason, these were not reached, the entire load of medical waste shall be reprocessed. Proper records of the treatment cycles and procedures used in batches to time and duration.

Microwaving

- Microwave treatment shall not be used for cytotoxic, hazardous or radioactive wastes, contaminated animal carcasses, body parts and large metal items.
- The microwave system shall comply with the efficacy tests mentioned below.
- Each microwave system shall be provided with temperature probes at the pathogenic organism that is assumed to be the approved location at the maximum design capacity of each microwave unit.

Deep Burial

- A pit of 2 meter should be dug about 2 m deep. It should be filled with lime, soils and then covered with lime and soil. Burial of the wastes before filling the rest of the pit with soil.
- It must be ensured that animals do not have access to burial sites.
- Covers of galvanized iron mesh must be used.
- On each occasion, when wastes are added to the pit, a layer of 15cm of soil be added to cover the wastes.
- Burial must be performed under close and watchful supervision.
- The site should be relatively impermeable and no shallow well should be close to the site.
- The pits should be distant from habitation, and shall so as to ensure that no contamination occurs of any habitation, well or surface water.
- The area should not be prone to flooding or erosion.
- The location of the site should be authorized by the prescribed authority.
- The institution shall maintain a record of all pits for deep burial.

Disposal of Sharps

- Blades and needles made after disinfection should be disposed in shredder or rectangular pits.
- Such pits can be dug and lined with brick, masonry, or concrete rings.
- The pit should be approximately 2 meters deep and the sharps should be disposed in a galvanized iron mesh container to about 1.5 m deep into the pits. Lime should be sprinkled at each 15 cms.
- When the pits is full it can be sealed completely after another has been prepared.

Radioactive waste from medical establishments

- It may be stored under carefully controlled conditions until the level of radioactivity is so low that they may be handled as other waste.
- Special care is needed when lab equipment containing radioactive source is being discarded.
- Dose rate should also be taken into account.

Mercury control

Wastes containing Mercury due to breakage of thermometer and other measuring equipment need to be given

- Proper attention should be given to the collection of the spilled mercury, its storage and sending of the same back to the manufacturers.
- Port lists of measures to ensure that the spilled mercury does not become part of biomedical wastes.]

- Waste containing mercury ought to store that its ratio of mercury to total waste and the concentrat of mercury in the leachate from the waste does not exceed the limits specified in the Hazardous waste rules.

Standard for Liquid Waste

The effluent generated from the hospitals must confirm to the following:

Parameter	Permissible limit
pH	6.5 – 9.0
Suspended solids	100 mg/l
Oil and grease	10 mg/l
BOD	30 mg/l
COD	250 mg/l
Wastes test	90% survival of fish after 96 hours in 100% effluent

These limits are applicable to those hospitals which are either connected with sewers that have its terminal sewage treatment plant or not connected to public sewers that have terminal facilities. In addition, the general standards as specified by the Central Pollution Control Board, Delhi, should be followed.

Waste minimization: Waste minimization is an important first step in managing wastes safely, responsibly and in a cost effective manner. This management step involves use of reducing, reusing and recycling principles. There are many simple and practical ways in which waste minimization can be achieved in hospitals and other sources of medical facility. Alternative technologies for biomedical waste minimization (i.e. microwave treatment, hydroclave, autoclave, chemical disinfection, incinerator, deep burial) are also discussed in the following sections of this chapter.

Different Types of PPE according to Risk:



The World Health Organization (WHO) has classified medical waste according to their origin, density and constituents into different categories. These are:

Infectious: Medical waste suspected to contain pathogens (bacteria, viruses, parasites or fungi) in sufficient concentration or quantities that, if exposed, can cause disease. Examples include waste contaminated with blood and other potentially infectious body fluids, disposable needles, syringes, gloves, blades, broken glasses, vials or any other item that could cause a cut.

Pathological: Human tissues, organs, body parts, blood and body fluids, fetuses and animals that are intentionally or accidentally infected, suspected to be infected, or used for research.

Radioactive: Liquids, liquids and gaseous waste contaminated with radioactive substance used in diagnosis and treatment of diseases like toxic gallbar, and.

Others: waste from the offices, kitchens, rooms, including bed linen, utensils, paper, etc.

Health hazards

According to the WHO, the global life expectancy is increasing year after year. However, there is a resurgence in infectious diseases and also increasing, in many countries, the number of people suffering from chronic diseases and disorders from infectious diseases. One of the causes for the increase in infectious diseases is the improper management of medical waste. Sharps, blood and body secretions which are constituents of the medical waste harbour pathogens that can cause infections in humans and other living beings.

This causes one is a number of human contacts, all of whom are potential recipients of the infection. Human immunodeficiency virus (HIV) and hepatitis B and C viruses are the most serious infections that are documented to have spread through bio-medical waste. Tuberculosis, meningococcal infection, Staphylococcus Aureus, Pseudomonas, Klebsiella, Hemophilus influenzi etc. are other common diseases spread due to improper waste management.



Occupational health hazards

The health hazards due to improper waste management can affect

- The occupants in institutions and spread in the vicinity of the institutions.
- People happened to be in contact with the institutions like laundry workers, nurses, emergency medical personnel, and refuse collectors.
- Risks of infections and injuries for waste handlers, scavengers and sanitarians the general public.



- Exposure to cytotoxic drugs, genotoxic chemicals, drugs, being handled by contract/sanitary workers at all levels.



- Injuries from sharps and exposure to harmful chemical waste and radioactive waste also cause health hazards to employees.

Hazards to the general public

The general public's health can also be adversely affected by bio-medical waste.

- Improper management of bio-medical waste can lead to bio-medical wastes, even spouse, water bodies and underground water.
- Emissions from incinerators and open burning also lead to exposure to harmful gases which can cause cancer and respiratory disorders.
- Exposure to radioactive waste in the waste stream can also cause serious health hazards.
- An effort ignored area is the increase of in home healthcare activities. An increase in the number of diabetics who inject themselves with insulin, hypodermic needles and chemicals ill patients etc., all generate bio-medical waste in the home environment.

Bio-medical wastes can cause health hazards to animals and birds too

- Plastic waste can choke animals, which scavenge on open dumps.
- Cattle from strays are common feature affecting animals.
- Harmful chemicals such as alcohols and furans can cause serious health hazards to animals and birds.
- Heavy metals can even affect the reproductive health of the animals.
- Change in microbial ecology, spread of antibiotic resistance

What can be done?

- Use only disposable syringes. after use throw the syringes after breaking them
- Bandages, cotton and other blood stained materials should not be thrown with general garbage
- Use black plastic bags to dispose biomedical waste.
- Keep trash can of each of small children at home
- Diapers, Sanitary napkins etc. should also be disposed separately
- Ensure that one dust date of waste must never be used

Dos and Don'ts

Ensure

1. That the used product is modified.
2. That the used product is properly disposed.
3. That the used product is segregated.

Do not

1. reuse plastic equipment.
2. mix plastic equipment with other wastes.
3. burn plastic waste.

Conclusion:

We need innovative and radical measures to clean up the distressing picture of lack of civic concern on the part of people. Public awareness campaigns should be launched to educate the people on the ill effects of improper biomedical waste treatment and disposal through direct and indirect costs on society. The challenge before us therefore, is to develop and implement a comprehensive, efficient and environmentally sound system for management, handling and disposal of health care waste that is also financially sustainable.

Sources for the materials and illustrations used in this publication are the following:

1. "Bio-medical waste management", Environmental Management and Policy Research Institute, Bangalore, 2004.

2. "Guidelines for management of liquid waste streams in biomedical wastes", Environmental Health Engineering Cell, Central Pollution Control Board, Delhi, 2000. Available at http://www.cpcb.nic.in/bmw.htm

3. "Southern regional conference on bio-medical waste management" Tamilnadu Pollution Control Board, Chennai, India.

4. "Manual on hospital waste management", Central Pollution Control Board, Delhi, 2000.

5. "bio-medical waste", Toxics Link – Factsheet, Number 31, 32, 33, 34, 2000.

6. "Understanding and Simplifying Bio-Medical Waste Management" – Training Manual

7. Private hospitals doing better in biowaste management (A Luna Zone, Pre-Study).

8. State of the environment report 2003

9. Web sites:
   a. http://www.projectsatthirdcrossroad.com
   b. http://www.cpcb.nic.in
   c. http://toxics.ban.nic.in/BMW/
   d. http://www.intrakleen.com/
   e. http://www.ehsdb.com/bio-management.pdf
   f. http://www.thehackthis.com/